# USB/RS232 DONGLE FOR WM-E2S MODEM

USB adapter for configuration of the WM-E2S® ITRON compatible modems

This adapter has two parts: USB/RS232 DONGLE and an RJ45-RJ45 converter cable.

The RS232 compatible USB Dongle has an USB connector (for connecting a PC) and an RJ45 socket to connect the WM-E2S (ITRON® compatible) modem by its RJ45-RJ45 cable.

After the connection, the modem will be reconfigurable with our WM-E Term® software.
This configuration tool is also suitable to perform firmware refresh (OTA updates).

APPLICATION

- WM-E2S
- WM-E2S PME-PMI

MAIN FEATURES

- RS232 port
- Local reconfiguration of the modem
- Safe local firmware updates